

Thank you for purchasing this AquaTech M3 Pistol Grip. The AquaTech M3 Pistol Grip is designed to work with the AquaTech Sport Housings. The Pistol Grip allows the photographer to steer the housing and trigger the shutter with a single hand.

Overview:

AquaTech has released a pistol system for their Canon and Nikon Housings. The switch is very sensitive and direct which ensures no shots are missed, while the grip has been redesigned to be lighter and more ergonomic in your hand.

Includes all mounting hardware and wiring including the waterproof shutter release switch and cable release. Simple "plug and play" installation.

The AquaTech Pistol Shutter Release feature a focus control and shutter control. When using the pistol grip, zone focus will produce sharper, more consistent images.

What's in the Box

- M3 Pistol Grip
- Instructions
- Mounting Hardware
- Required Tool
- Instructions

Table of Contents

- [Whats in the Box](#)
- [Nomenclature](#)
- [Initial Setup](#)
- [Using the M3 Pistol Grip Underwater](#)
- [Safety information](#)
- [Maintenance and Repair](#)
- [Limit of Liability](#)
- [Warranty](#)
- [Servicing](#)
- [Returns](#)
- [Legal](#)

Initial Setup

Attach the camera cable release to your camera's cable release jack, ensure you have the correct cable release for your camera and do not force into your camera. Attach the male mini jack connector at the other end of this cable into your internal female plug which is located in the bottom left hand side inside your housing. Place your camera inside your housing and secure for use as normal. (Please refer to Sport Housing Instructions). Attach the waterproof switch to the outside female bulkhead on your Sport Housing.

The 3 male pins should engage smoothly and should not require any force. The trigger should sit flush with the bulkhead. This female bulkhead on the Sport Housing is waterproof and does not require sealing when not in use. The male plug provided is to help prevent corrosion and build up of foreign matter.

Attach the Pistol Grip handle to the bottom of your Sport Housing by using the supplied M5 x 16mm bolts and the Hex Key for these bolts. The trigger should sit comfortably in the pistol's trigger groove and fire when pressure is applied to the trigger's main buttons.

We suggest that the 2 button switch should remain in the Pistol Grip handle at all times even when not in use and when removed from your Sport Housing.

When removing the Pistol grip from your Sport Housing, release from the female inline bulkhead at the Sport Housing connection. Do not pull or apply unnecessary pressure to the cable itself or the focus fire buttons as damage may occur.

If your Pistol Grip is not firing when triggered, ensure the internal connections are correctly setup and the cameras cable release is the correct model for your camera.

Using the M3 Pistol Grip Underwater

For best results please make sure you have carefully followed all initial setup instructions prior to taking your M3 Pistol Grip underwater.

Safety Information and Warning

Do not exceed depths of 10m/33ft.

Maintenance and Repair

With proper care your M3 Pistol Grip will last for many years. If in time you do notice any problems that come up or if there is any damage to the equipment please contact AquaTech directly at service@aquatech.net for repairs or servicing.

Limit of Liability

In the event of a product warranty claim, AquaTech is only liable up to the value originally paid for the product.

Losses of associated equipment, income or any other financial costs are not covered under this warranty, under any circumstances.

Warranty - 1 Year Product Warranty

We make every effort to ensure that our products are made from the highest quality materials and workmanship. Should you not be completely satisfied with one of our products, we encourage you to contact us so that we can promptly resolve any problem you may be experiencing. Our company representatives will deal with your issue quickly and decisively.

As many AquaTech products are often used in extreme and volatile environments, we are unable to cover for loss or damage of equipment, personal injury or financial loss.

To reduce the risk of these losses occurring, we strongly recommend you read the relevant product instructions carefully and test the product before use.

What does the warranty cover?

This warranty covers any defects in materials or workmanship, with exceptions stated below

What is not covered?

The warranty does not cover damage as the result of normal wear and tear. Determination of what constitutes normal wear and tear will be at the discretion of AquaTech service centers. The warranty guarantee only applies to the original purchaser

of the product when purchased from AquaTech direct or through one of our authorized dealers. Therefore, we may ask for proof of purchase. This warranty does not cover for any loss of associated equipment such as cameras, lenses or other associated equipment not sold by AquaTech.

Loss of income, reputation or other financial expenses, such as personal injury are also not covered by this warranty. Shipping costs for returned products are the responsibility of the customer.

How long does the coverage last?

This warranty runs for 1 year from the date your product is received.

What will AquaTech do?

AquaTech will repair any defect that proves defective in materials and workmanship. If repairing is not possible, AquaTech will replace the product, or, offer a store credit for the original purchase price, whichever is agreed to by the customer and AquaTech / Retailer store.

How to get service?

Email contact@aquatech.net and we will advise where to send your product. Alternatively, you may call:

USA: + 1 714 968 6946 Australia: + 61 2 4268 3550

Returns Policy - Aquatech Online Customers only:

AquaTech offers a 14 day return policy for new items purchased directly through our online store or at our physical store. AquaTech will only provide exchanges or store credit for change of mind or incorrectly ordered products. AquaTech will not refund any shipping and credit card costs. Please see our full return at <https://aquatech.net/pages/return-policy>. The customer is responsible for shipping cost of the returned items. A restocking charge may be applied in some countries

How State Law Applies:

This warranty gives you specific legal rights, and you may have other rights which vary according to the state or country in which you are located.

Legals

Please practice extreme caution when diving into deep water. Only use this product in settings that are within yours or other's capabilities. Serious injuries or drowning could occur if you or others are not competent for the prevailing conditions.

AquaTech (NSW) Pty. Ltd., incorporated in Australia. Australian Business Number: 84 062 580 796